


Installation Instructions

Honeycomb Shades

Corded / Corded TDBU / Corded Day & Night



Getting Started

Remove the shade from the package. Save the packaging until the shade is installed and working to your satisfaction.

Tools Needed :

- Power drill and drill bit
- Measuring tape
- Screwdriver
- Level
- Pencil



You will need to use the following fasteners for your particular mounting surface.

Surface	Fastener
Wood	1 1/4" Screws (Provide) for 3/8"S
	for 3/8"D & 3/4"S
	3/4" Screws (Provide)
Drywall/Plaster	Wall Anchors, Expansion Bolts (Not Provide)
Metal	Sheet Metal Screws (Not Provide)

Check Component/Hardware:



for 3/4"S for 3/8"D & 9/16"S for 3/8"S

Installation Bracket



Cord Cleat



Hold Down bracket (optional)

Hardware Standard Quantity

Order Width (X)	8 1/2" ≤ X ≤ 42"	42" < X ≤ 75"	X > 75"
Installation Bracket	2	3	4
1 1/4" Screw for 3/8"S Installation Bracket	2	3	4
1 1/4" Screw for 3/4"S & 3/8"D Installation Bracket	4	6	8
Cord Cleat	1pc for Corded, 2pcs for Corded TDBU & Day & Night		
3/4" Screw for Hold Down Bracket/ Cord Cleat	Hold Down Bracket qty*2 + Cord Cleat qty		
2" Screw for Installation Bracket with spacer	4	6	8
Hold Down Bracket (Optional)	2	2	2
Spacer (Optional)	2	3	4


Note: You may find more hardware parts than you actually need. In that case, feel free to set them aside for future use.

* Cord cleat is included.

* Optional hardware parts, such as spacers and hold down brackets, are available upon request.

Step 1: Bracket Installation

Measure 3" from both ends of the head rail. Mark the bracket location on the mounting surface. Proper alignment of brackets will make installation easier.




a. for 3/8" Double cell, 9/16" Single cell & 3/4" Single cell

Inside Mount:

Allocate a min. distance of 3/16" from wall to the front of brackets. Use two 1 1/4" mounting screws to secure brackets. Use wall anchors for drywall or plaster wall. (Align the front of brackets flush with wall if only lock the back hole in the brackets.)

Outside Mount:


Allocate a min. distance of 5/16" from the end of brackets to the top window frame. Use two 1 1/4"



mounting screws to secure brackets. Use wall anchors for drywall or plaster wall.


b. for 3/8" Single cell Inside Mount:

Allocate a min. distance of 5/16" from the edge of the wall to the front of brackets. Use two 1 1/4" mounting screws to secure brackets.




Outside Mount:

Allocate a minimum distance of 3/16" from the end of brackets to the top window frame. Use two 1 1/4" mounting screws to attach each bracket.




** For shallow mounting, using flat head screw to secure the bracket in 45° .*



Step 2: Shade Installation


- Position the shade so that the front is facing you.
- Insert the rail with an angle facing the window; hooking up with the bracket front side, and then push it upward to snap into the bracket. For proper installation, start with attaching the front rail to the bracket.



Step 3: How to Install Hold Down Brackets (optional)


A, For Hold Down Bracket.

Use two 3/4" screws to secure each hold down bracket.



B. For Magnetic Hold Down

Use M3x15mm screw to secure the magnet catch at the below location. Make sure the magnet catch align with the pre-installed magnet on shade bottom rail.




Step 4: Shade Operation

For Corded TDBU & Day & Night: when lowering the shade, pull the left cord to lower the bottom rail first and then pull the right cord to lower the middle rail. When raising the shade, reverse operation. Raise the middle rail first and then bottom rail.

Step 5: Cord Cleat

Install the cord cleat on the wall. Wrap the operating cords around the cord cleat for child safety. Always use the cord cleat to keep cords out of the reach of children. The cleat should be installed more than 64" (1.6m) from the door.




Remove the Shade

- For Corded, Fully raise the shade
- For Corded TDBU & Day & Night, Lower the mid rail
- Insert screwdriver into the gap between the back of the rail and the bracket. Gently maneuver the screwdriver toward yourself to pry the bracket.



How to Reassemble Ellipse Safety Cord Connector



Our Shade comes equipped with an Ellipse Safety Cord Connector that prevents child strangulation. If the device comes apart, please refer to below steps:

1. Open the Ellipse Safety Cord Connector entirely.
2. Align all cords and slide them into the slot of Ellipse Safety Cord Connector;
3. Close the Ellipse Safety Cord Connector;
4. Pull the tassel cords and make sure it is closed tightly

Safety Warning

Warning! Children can become entangled and strangle in window shade cords. Keep all cords out of reach from children. Move cribs and other furniture away from window coverings with cords. The following devices are recommended:

- Cord cleat (included)
- Clip/Clamp
- Tie the cord to itself
- Use any tie-down device



Young children can **STRANGLE** in cord and bead chain loops. They can also wrap cords around their necks and **STRANGLE**.

- Always keep cords out of children's reach.
- Move cribs, playpens, and other furniture away from cords and bead chains.

Children can climb furniture to get to cords.

- Always wrap the cords around the cleats in a figure eight, up high, out of reach of children.



Un jeune enfant peut s'**ÉTRANGLER** avec la boucle d'un cordon ou d'une chaînette. Il peut aussi entourer le cordon autour de son cou et s'**ÉTRANGLER**.

- Gardez toujours les cordons hors de portée des enfants.
- Éloignez les lits et parcs de bébé, ainsi que toute autre pièce de mobilier, des cordons et des chaînettes. Un enfant peut grimper sur un meuble pour atteindre les cordons.

Enroulez toujours les cordons en noeud en huit autour du taquet de cordon, placé haut et hors de portée des enfants.


Cleaning

Routine cleaning will help maintain the beauty of your shade. The shade can be cleaned by using a soft brush, vacuumed with a low suction hand-held

vacuum, cleaned ultrasonically (specify that a mild solution must be used and that the head rail should never be immersed in liquid), or dampen a clean cloth with a warm water and mild detergent solution to dab the spot until it's gone (do not rub!).


Troubleshooting

Problem	Solution
For corded TDBU & Day & Night, if the bottom shade fabric not remain stacked (billowed on the windowsill), when the top was lowered	When lower the bottom shade, please pull the left side cord leftwards to lock the bottom rail. Please make sure the bottom rail is locked right above the windowsill first (if not locked, please try more times) before operating the top shade.



Inner cords can pull out to form a loop, which can STRANGLE a young child.

- Inner cord stop devices can reduce this risk if positioned correctly on the operating cords.
- If inner cord stop devices are more than 76 mm (3 in) below the headrail when the blind is fully lowered, move them closer by following the inner cord stop device adjustment instructions.



Las cuerdas internas pueden sacarse para formar un lazo en que puede ESTRANGULARSE un niño pequeño.

- Los dispositivos de paro de la cuerda interna pueden disminuir este riesgo si están situados correctamente en el halado de las cuerdas.
- Si los dispositivos de paro de cuerda interna son más de 3 pulgadas (76 mm) por debajo del riel superior cuando está bajada o completamente la persiana, muévalos siguiendo las instrucciones del ajuste de paro de cuerda interna.



Les cordons intérieurs peuvent sortir pour former une boucle et ÉTRANGLER un jeune enfant.

- Les dispositifs d'arrêt des cordons intérieurs peuvent diminuer ce risque s'ils sont placés correctement sur les cordons.
- Si les dispositifs d'arrêt des cordons sont situés à plus de 76 mm (3 po) en dessous du rail supérieur quand le store est complètement baissé, rapprochez-les en suivant les instructions de réglage du dispositif d'arrêt du cordon intérieur.